BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This set of Speaker Pods is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

NOTE:

- 1. This product does not include speakers.
- 2. This product is suitable for 6.5" speakers.



1. Place the the prepared speakers in the speaker mounts, then use an M5 drill bit to drill holes in the mounts along the existing holes on the speaker to align them, and then use the matching screws and nuts to fix the speakers to the mounts (the speaker wiring harness needs to be connected by oneself) as illustrated:





2. Remove the retaining screw from the vehicle's original side panel, then position the speaker pod in the properly aligned location and reinstall the original screw. Finally, secure the pod by driving the included self-tapping screws into the corresponding mounting holes in sequence. (Repeat the same procedure on the opposite side) as illustrated:

Note: If difficulty is encountered when installing self-tapping screws, pre-drill pilot holes using an M3 drill bit prior to screw insertion. This will significantly improve installation ease.



Golf Speaker Mounts for E-Z-Go RXV







3. Installation completed!

