Mesh Grille with LED Light for Can-Am Defender





BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

The Mesh Grille with LED Light is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

Product and accessories picture:



1. First, remove the original vehicle grille, move the steel clips on the original grille to the new grille in their original positions, then disconnect the wiring harness plug of the original headlight (on the driver's side), prepare the matching adapter wire to re match it with the vehicle wiring harness and the original headlight plug, and then pull the extension wire on the adapter wire through the gap of the vehicle to the grille and connect it with the wiring harness plug of the new grille. Finally, install the new grille. As shown in picture:

Note: There are 2 screws on the grille, and the angle of the grille spotlight can be adjusted according to the actual situation.







Mesh Grille with LED Light for Can-Am Defender







Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

2. Installation completed!

