

Combined Fender Flares for Club Car Tempo

SAUTVS®

ZP-YJ-031903-001

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

This *combined fender flare* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

PRODUCT



INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Use the matching M4 self-tapping screws to assemble the front and rear fender flares into a whole respectively. As shown in the figure:



3. The installation methods for the front and rear fender flares are the same. Just place the fender flares at the corresponding positions on

Combined Fender Flares for Club Car Tempo

ZP-YJ-031903-001

SAUTVS®

the vehicle, and then fix them in sequence using the provided self-tapping screws and flat washers (the other side is also assembled and installed in the same way). As shown in the figure:

Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.



4. The installation is complete.

