

Rear Bumper for Polaris Sportsman 500

ZP-YJ-030506-042

SAUTVS®

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

This *rear bumper* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Use two M8*45 hex socket screws and two M8 anti-loosening nuts to combine Part 1 and Part 2 through a sleeve (Part 3), as shown in the following figure:



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

3. Then, install the rear bumper onto the rear frame with four M8*20 flange external hexagon self-tapping screws. Tighten the screws and complete the installation, as shown in the illustration: