

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

This *fender flare* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

PRODUCT



INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

Front Fender Flare:

1. First, use the M4 self-tapping screws provided with the product to assemble the split fender flare into a complete unit. As shown in the figure:





2. Place the assembled front fender flare in the corresponding position on the vehicle, then secure it using the included M6 self-tapping screws and flat washers. As shown in the figure:



Fender Flares for E-Z-GO RXV

ZP-YJ-041310-001





Rear Fender Flare:

1. The installation method for the rear fender flare is the same as for the front fender flare. First, assemble the rear fender flare into a complete unit using the M4 self-tapping screws. Then, position it in the corresponding location on the vehicle. Finally, secure it using the M6 self-tapping screws and flat washers. (The other side's is assembled and installed in the same manner.) As shown in the figure:









Fender Flares for E-Z-GO RXV

ZP-YJ-041310-001



2. The installation is complete.





Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.