

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This REAR SEAT SPEAKER PODS KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

2. Product image.

(NOTE:This product does not include speakers, and compatible with 6.5-inch speakers.)



3. First, distinguish the left and right sides of the speaker brackets. Next, position the speaker brackets at the corresponding locations on the vehicle. Then, prepare a 6mm drill bit and drill holes sequentially according to the screw hole positions on the speaker brackets.



4. After drilling, secure the assembly using M6*20 screws and matching flat washers. Finally, attach the speaker you provided to the bracket using the included self-tapping screws (the wiring harness of the speaker needs to be connected by yourself). Install the other speaker bracket using the same method described above.

Rear Seat Speaker Pods for Can-Am Maverick X3

YAP-030603-210

SAUTVS



5. Installation complete.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.