

Spare Tire Mount for Can-Am Maverick X3

SAUTV5

ZP-YJ-030603-210

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This SPARE TIRE MOUNT KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Product image.



3. Secure the upper end of the spare tire mount to the rear frame using two M6*70 hex bolts and two M6 lock nuts, as shown in the illustration.



4. Attach the lower end of the spare tire bracket to the rear frame using four M8*30 hex bolts and four M8 lock nuts through the semi-circular iron bracket, as shown in the figure.



Spare Tire Mount for Can-Am Maverick X3

ZP-YJ-030603-210

SAUTVS®



5. Tighten all screws and nuts. Installation complete.

