

LED Taillights for Can-Am Outlander 1000R

SAUTV5

YAP-030602-071

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

This *LED Taillight* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

PRODUCT



INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. First, remove the seat cushion, then detach the rear bumper and rear storage platform. As shown:

Note: There is one screw on the inner side of the battery cover, which requires opening the battery cover for removal.



LED Taillights for Can-Am Outlander 1000R

YAP-030602-071

3. Remove the mounting bracket of the original taillight, unplug the wiring harness connector. Then detach the original taillight from the bracket. Install the new taillight and secure it using the original vehicle screws. As shown in the figure:

the new taillight onto the vehicle, and reconnect the wiring harness connector. Then start the vehicle, press the brake pedal, and check if the taillight functions properly. Once confirmed, reattach the previously removed rear bumper and storage platform to their original positions. As shown in the figure:



4. Reinstall the assembled mounting bracket of

LED Taillights for Can-Am Outlander 1000R

YAP-030602-071

SAUTVS®

5. The installation is complete.

