

# Aluminum Air Intake Grille Covers for Polaris Xpedition 2024+



YAP-030503-279

## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

## IMPORTANT

The *Grille Covers* are exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

**Note:** Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

## INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

Product picture



1. Align the small grille cover with the side position, then use an electric drill to mark the locations of the 4 mounting holes, as shown in the picture:



# Aluminum Air Intake Grille Covers for Polaris Xpedition 2024+



YAP-030503-279



2. Secure the small grille cover using 4 M4\*10 hexagon socket self-tapping screws.



3. Align the large grille cover with the side position, then use an electric drill to mark the locations of the 6 mounting holes, as shown in the picture:

# Aluminum Air Intake Grille Covers for Polaris Xpedition 2024+

YAP-030503-279



4. Install the large grille cover using 6 M4\*10 hexagon socket self-tapping screws. Tighten all screws to complete the installation.

# Aluminum Air Intake Grille Covers for Polaris Xpedition 2024+



YAP-030503-279

---



5. The installation is complete.