

Center Mirror Tab Cover Plate for Can-Am Maverick X3 / R

SAUTV5[®]

YAP-030603-264

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This CENTER MIRROR TAB COVER PLATE KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Product image.



3. Use 2 M6×16 hex socket screws, 2 M6 flat washers, and locknuts to secure the aluminum cover plate in the position shown in the figure. Installation is now complete.

