

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This HANDGUARDS PROTECTOR KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Product image.



3. First, remove the original handguard bracket from the vehicle.



Hand Guards Protector for Can-Am Canyon

4. Install the new handguard onto the bracket using the screws and flat washers provided with the product. Then reinstall the handguard bracket onto the vehicle. (Repeat the above steps for the other side.)



5. Installation complete.

