

Aluminum Air Intake Grille Covers for Can-am Commander 2021+



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT


The Grille Covers are exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

Product picture



1. Remove the 10 screws from the air intake filters on both sides of the original vehicle, as shown in the picture:



2. Secure and install the protective grille covers with 10 original screws.



3. The installation is complete.