

Center Rear View Mirror for Polaris Ranger XD 1500

SAUTVS®

YAP-C30505-048

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

This *Center Rear View Mirror* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

PRODUCT AND ACCESSORIES



No.	Item	Qty.
1	Center mirror assembly (Incl. Screw)	1pc
2	Bracket	1pc
3	Hex flange screws, M8*16	2pcs
4	Christmas Tree Fastener, 8mm	2pcs

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. First, remove the original overhead switch panel from the vehicle roof and disconnect its wiring harness connector, as shown in Figures 1-2:



3. Following the installation orientation indicated in the pictures, use M8×16 screws to secure the interior rear view mirror mounting bracket to the mounting points on the vehicle (Figure 3). Then, remove the screw from the rear cover of the rear view mirror, pass that screw through the hole on the mounting bracket, and re-tighten it to fix the mirror onto the bracket (Figures 4-5). Finally, reconnect the wiring harness connector to the original overhead switch panel and reinstall the panel back to its original location (Figure 6).

(Note: If the plastic Christmas tree fasteners that secure the original overhead switch panel are damaged during removal, you may use the spare screws provided in the accessory kit.)

Center Rear View Mirror for Polaris Ranger XD 1500

YAP-C30505-048

SAUTVS®



4. The installation is complete.

