

Half Windshield for Can-Am Defender



YAP-030611-030

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

The Half Windshield is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

Product and accessories picture:



secure the half windshield to the lower part of the front frame using two metal brackets. Tighten the screws and nuts to complete the installation.



1. Use two small straps to secure the half windshield to the upright post, as shown in the figure.



2. Use four M6 × 20 hex socket screws, two M6 flat washers, and four M6 lock nuts to

Half Windshield for Can-Am Defender

YAP-030611-030

SAUTV5[®]

