

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This FRONT FENDER KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.



2. First, use the screws, flat washers, and nuts provided with the product to mount the corresponding fenders to the wheel arches, as shown in Figures 1–3.



3. Remove the vehicle's original wheel fenders (after removing the wheel fenders, disconnect the wiring harness connector for the wheel fender lights), as shown in Figures 4–6.



4. Remove the mounting brackets and fender lights from the vehicle's original wheel arches, then transfer them to the new wheel arches in their original positions and secure them with the original screws (the fender lights are snap-fit; you can remove them simply by using a pry bar). Finally, reinstall the new wheel arches on the vehicle (make sure to connect the fender light wiring harness connectors before installation), and repeat the same steps on the other side to complete the replacement and installation. See Figures 7–10.





5. Installation complete.

