

Under Seat Storage Box for Honda Pioneer 520

ZP-YJ-030908-020

SAUTV^{VS}

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

This *Under Seat Storage Box* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

PRODUCT



INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Remove the driver's seat cushion and then take off the cover under the driver's seat. As shown in the figure:



3. Place the storage box in the groove, then use the M8 drill bit to drill holes according to the corresponding screw holes on the storage box. Finally, fix it with the snap fasteners and reinstall the seat cushion. As shown in the figure:



Under Seat Storage Box for Honda Pioneer 520

ZP-YJ-030908-020

SAUTV^{VS}



4. The installation is complete.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.