

Airbox Cover Assembly for Polaris RZR XP 1000



YAP-030503-220

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

The *Airbox Cover* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS


Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

Product picture



1. First, install the product's matching locks and sealing strip onto the new upper cover. As shown:

Note: The sealing strip is trapezoidal in shape, install it with the narrow side facing downward.



Airbox Cover Assembly for Polaris RZR XP 1000

YAP-030503-220



2. Remove the original air filter upper cover and replace it with the new one. As shown:



3. Installation complete.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.