

LED Accent Lights for Polaris RZR XP 1000 2026

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

The LED Accent Lights are exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into “PARK”. Turn key to “OFF” position and remove from vehicle.

Product picture




No.	Item	Quantity
1	LED Accent Light L	1
2	LED Accent Light R	1
3	White Wire	2

1. Unscrew the switch valve of the original vehicle's grille and remove the grille as shown in Figure 1-2:



2. Use an 11mm open-end wrench to remove the original vehicle's fang-shaped trim pieces, as shown in Figures 3-4:


LED Accent Lights for Polaris RZR XP 1000 2026



Sheet metal nut

3. Prepare the fang-shaped lights. First, connect the original vehicle's pre-wired harness connector to the accent light harness connector. Then, turn the original vehicle key to check if the accent light illuminate properly. Once confirmed, use the original vehicle's sheet metal nuts to secure and install them, as shown in Figures 5-7 (install the other accent light using the same method). Finally, reinstall the original vehicle's grille, as shown in Figure 8.

Note: This product comes with a turn signal function (yellow wire), which can be connected DIY as needed.(Prepared turn signal flasher controller by customer in advance).



LED Accent Lights for Polaris RZR XP 1000 2026



4. The installation is complete.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

