

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This LED HEADLIGHTS KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

- 1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
- 2. Product image.





3. First, remove the original hood and the front fascia trim panel.





LED Headlights for Can-Am Maverick R

ZP-YJ-030601-011










4. Remove the original headlight from the front fascia.






5. Move the rubber ring and adjusting screw on the original headlight to the new headlight according to the original position, and then install the new headlight to the front fascia, and use the original screws to fix it. (The other side of the headlamps can be replaced and installed in the same way.)



LED Headlights for Can-Am Maverick R

ZP-YJ-030601-011








6. Reinstall the front fascia back into the vehicle and reconnect the headlight harnesses.





7. Prepare an extension cord, connect one end to the daytime running light harness on the new headlights (the connection needs to be well insulated and protected), pull the extension cord through the gap to the vehicle's ACC power supply, and connect the extension cord to the ACC screw post, and then finally install the previously disassembled decorative panels, hoods, and the mesh grille back to their original positions.





LED Headlights for Can-Am Maverick R

ZP-YJ-030601-011







8. Installation completed.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.